


LGS-A10

USER MANUAL



Compact LiDAR for Collision Avoidance and Object
Detection

DATA SENSING

Datasensing S.r.l.

Strada S. Caterina 235

41122 Modena

Italy

Tel. +39 059 420411

Fax +39 059 253973

© 2024 Datasensing S.r.l.

All rights reserved. Without limiting the rights under copyright, no part of this documentation may be reproduced, stored in or introduced into a retrieval system, or transmitted in any form or by any means, or for any purpose, without the express written permission of Datasensing S.r.l. Owners of Datasensing products are hereby granted a non-exclusive, revocable license to reproduce and transmit this documentation for the purchaser's own internal business purposes. Purchaser shall not remove or alter any proprietary notices, including copyright notices, contained in this documentation and shall ensure that all notices appear on any reproductions of the documentation. Electronic versions of this document may be downloaded from the Datasensing website (www.datasensing.com).

Disclaimer

Datasensing has taken reasonable measures to provide information in this manual that is complete and accurate, however, Datasensing shall not be liable for technical or editorial errors or omissions contained herein, nor for incidental or consequential damages resulting from the use of this material. Datasensing reserves the right to change any specification at any time without prior notice.

Trademarks

Datasensing and the Datasensing logo are trademarks of Datasensing S.r.l.

Patents

See www.patents.datasensing.com for patent list.

LGS-A10 is a trademark of Datasensing S.r.l. All other trademarks and brands are property of their respective owners.

ORIGINAL INSTRUCTIONS (ref. 2006/42/EC)

CONTENTS

PREFACE	IV
About this Manual	iv
Manual Conventions	iv
Technical Support	iv
Support Through the Website	iv
Reseller Technical Support	iv
DOCUMENT DESCRIPTION	1
SAFETY INSTRUCTIONS	2
Handle laser device properly	2
Handle electrical connection properly	2
WORKING PRINCIPLES	3
INSTALLATION AND USAGE	5
Mechanical connection	5
Electrical connection	6
Power and I/O connector	6
I/O's Power Supply	7
Ethernet connector	8
Communication	8
LEDs	11
DATA PACKET FORMAT	12
Overview	12
Definition of Header	13
Definition of Block	15
Data conversion	15
Angle calculation	15
Distance calculation	16
Calculation of signal strength	16
PARAMETER CONFIGURATION	17
Configuration through LGS pro PC software	17
Operating environment	18
Network environment	18
Using LGS Pro	18
Menu tabs	18
Online configuration	21
Offline configuration	23
Monitoring	24
Basic measurement	26
Zone set switch	28
Detection capability	29
Reset the LiDAR	30
Firmware upgrade	30
TECHNICAL PARAMETERS	32
TROUBLESHOOTING	34
DATA PACKET	35
MECHANICAL DIMENSIONS	36
RECOMMENDATIONS FOR MECHANICAL INSTALLATION	37
CLEANING OF SENSORS	39
Precautions	39
Required materials	39
Cleaning method	39

PREFACE

ABOUT THIS MANUAL

This User Manual (UM) is provided for users seeking advanced technical information, including connection, programming, maintenance and specifications.

Manual Conventions

The following conventions are used in this document:

The symbols listed below are used in this manual to notify the reader of key issues or procedures that must be observed when using the reader:



NOTE

Notes contain information necessary for properly diagnosing, repairing and operating the reader.



CAUTION

The CAUTION symbol advises you of actions that could damage equipment or property.




WARNING

The WARNING symbol advises you of actions that could result in harm or injury to the person performing the task.

TECHNICAL SUPPORT

Support Through the Website

Datasensing provides several services as well as technical support through its website. Log on to (www.datasensing.com).

For quick access, from the home page click on the search icon , and type in the name of the product you're looking for. This allows you access to download Data Sheets, Manuals, Software & Utilities, and Drawings.

Reseller Technical Support

An excellent source for technical assistance and information is an authorized Datasensing reseller. A reseller is acquainted with specific types of businesses, application software, and computer systems and can provide individualized assistance.

CHAPTER 1

DOCUMENT DESCRIPTION

In order to maintain the normal performance of the product and prevent damage to the device, please do not try to open the sensor.

- Read the description: please read all the safety and operation information before using this product.
- Keep the description: please keep all the safety and operation information properly for future reference.
- Pay attention to the warnings: please read all the warnings in the manuals and on the product carefully.
- Follow the instructions: please follow all the operation instructions in this manual.
- Maintenance instructions: please follow the instructions for troubleshooting, do not try to repair the equipment by yourself. Contact our technicians promptly to solve the problems.
- Any equipment damage caused by violating the above safety regulations shall not be covered by the warranty.

CHAPTER 2

SAFETY INSTRUCTIONS

HANDLE LASER DEVICE PROPERLY



This product emits an invisible laser beam with a laser safety rating of Class 1.



Please do not open the LiDAR cover without authorization because the laser might be still on after the cover is removed and the operator would be exposed to laser.



It is not guaranteed that the laser remains Class 1 safety status after opening the cover.

HANDLE ELECTRICAL CONNECTION PROPERLY



Disconnect the power supply when connecting or disconnecting electrical cables.



The power supply connected with the device must comply with the requirements included in the operation instructions.



Please connect the reference potential properly when using the device to avoid injury caused by equal potential current.

CHAPTER 3

WORKING PRINCIPLES

The LGS-A10 is a 2D LiDAR that scans the surrounding area in a single plane with the help of an infrared invisible laser beam. The LGS-A10 uses 2D polar coordinates to characterize the surrounding environment based on its measurement origin.

With a scanning angle range of 360°, the LGS-A10 can detect and output information of the angle, distance and signal strength of the target, which facilitating better target identification by SLAM systems.




Figure 1 - LGS-A10 working principle




Figure 2

The LGS-A10 measurement principle is shown in the figure above, and it uses the time-of-flight principle to measure distance. LiDAR emits laser pulses at uniform and very short intervals, and the laser light is reflected back when it encounters an obstacle. The LiDAR receives the reflected light signal and calculates the distance information between the object and the LiDAR based on the time difference (i.e., the time of flight of the laser) T between the emission and reception and the speed of light C . The calculation method is shown below.

$$D=c*T/2$$

Where:

D = distance

T = flying time

c = speed of light

CHAPTER 4

INSTALLATION AND USAGE

MECHANICAL CONNECTION

The LGS-A10 LiDAR can be mounted thanks to the four M3 screw holes located on the bottom side of the device, we suggest to use M3 x 8 screws.




Figure 1 - LGS-A10 Mounting interface

ELECTRICAL CONNECTION

The LGS-A10 has 2 pig tail connectors, a 12-pole M12 male connector for power supply and a 4-pole M12 D-coded female connector for Ethernet communication. As shown in the figure below.






Figure 2 - LGS-A10 Connection

Power and I/O connector

M12-12 Poles Male - pig tail. Length of pig tail cable = 200mm

The supply voltage must be between 9 and 30Vdc. Here below the connector pinout.

PIN #	PIN NAME	PIN DESCRIPTION	CONNECTION DIAGRAM	NOTE ON I/O STATUS	WIRING COLOR
1	+VCC	POWER			Brown
2	GND	GROUND			Blue
3	INPUT 1	ZONE SET SWITCH INPUT 1		INPUT # = HIGH if floating or connected to VCC_I/O INPUT # = LOW if connected to GND_I/O	White
4	INPUT 2	ZONE SET SWITCH INPUT 2			Green
5	INPUT 3	ZONE SET SWITCH INPUT 3			Pink
6	INPUT 4	ZONE SET SWITCH INPUT 4			Yellow
7	GND I/O	GROUND for I/O	Connect to the GND of the power supply to be used for the I/Os. In case I/Os have to work with the same power supply of the LGS-A10, connect this pin together with pin 2.		Black
8	OUT_1	DETECTION OUTPUT 1		No Target detection: $I_{load} > 0$ Target detection: $I_{load} = 0$	Grey

PIN #	PIN NAME	PIN DESCRIPTION	CONNECTION DIAGRAM	NOTE ON I/O STATUS	WIRING COLOR
9	+VDC_I/O	POWER for I/O	Connect to the +VDC of the power supply to be used for the I/Os. In case I/Os have to work with the same power supply of the LGS-A10, connect this pin together with pin 1.		Red
10	OUT_2	DETECTION OUTPUT 2		No Target detection: Iload > 0 Target detection: Iload = 0	Violet
11	OUT_3	DETECTION OUTPUT 3		No Target detection: Iload > 0 Target detection: Iload = 0	Grey/Pink
12	OUT_4	ERROR OUTPUT 4		No Error status: Iload > 0 Error status: Iload = 0	Red/Blue




Figure 3 - Power connector

I/O's Power Supply

To allow the I/Os to function, the pins 9 and 7 must be connected to the power supply that the outputs are to switch.

It is possible to use a voltage for the outputs different from that used to power the LiDAR (for example +24Vdc for the LiDAR, +12Vdc for the outputs), as long as it is within the range indicated in the technical data. If the outputs must have the same voltage used to power the LiDAR, connect pin 9 together with pin 1 and pin 7 together with pin 2.

Ethernet connector

M12-4 Poles Female - pig tail. Length of pig tail cable = 200 mm

The pin definitions of Ethernet connector are as follows:

No.	DEFINITION
1	Transmit data +
2	Receive data +
3	Transmit data -
4	Receive data -




Figure 4 - Ethernet connector

COMMUNICATION

The standard Ethernet RJ-45 connector is used to connect the LGS-A10 to the computer. The computer IP address needs to be set before communication, the first three segments of the computer IP address must be set the same as the LiDAR (192.168.1.X) and be in the same subnet. The last segment of the computer IP cannot be set to 100 to prevent conflict with the LiDAR default IP.

Port number of the point cloud packet is 2368

The default factory settings for LiDAR are shown below:

- LiDAR IP:192.168.1.100
- LiDAR subnet mask: 255.255.255.0

The recommended computer IP settings are shown below:

- Computer IP: 192.168.1.10
- Computer subnet mask: 255.255.255.0

The setting process in the computer is shown below:




Figure 5 - Computer IP Setting: Step 1




Figure 6 - Computer IP Setting: Step 2





Figure 7 - Computer IP Setting: Step 3



NOTE

















When network addresses (IP LiDAR, IP Host, Net Mask, etc.) are changed, a power cycle of the LGS-A10 should always be performed. This way when the device reboots, it uses the new values.

LEDS

There are 2 LED indicators.



Figure 8 - LGS-A10 LEDs

LED	MEANING
 	Power On. Red and Green lights are always ON.
 	Start. Device self checking, Red and Green LED flash.
 	Normal operation. Red OFF, Green LED flash.
 	Fault. Red ON, Green LED flash.
 	OUT1 activation. Green ON, Red flash. TON1=0.4s; TOFF1=2s
 	OUT2 activation. Green ON, Red flashes 2 times. TON1=0.4s; TOFF1=0.4s; TON2=0.4s; TOFF2=2s
 	OUT3 activation. Green ON, Red flashes 3 times. TON1=0.4s; TOFF1=0.4s; TON2=0.4s; TOFF2=0.4s; TON3=0.4s; TOFF3=2s
 	Multi Area. Green ON, Red flash. When any two areas are triggered simultaneously, the alarm status of the intercepted area with higher priority is displayed. Priority level: OUT 1 > OUT 2 > OUT 3

CHAPTER 5

DATA PACKET FORMAT

The LGS-A10 enables laser point cloud data transmission. Please refer to the following for the analysis of LiDAR point cloud data.

The transmission of information between the LGS-A10 and the PC follows the UDP standard network protocol. The data is in Little-endian format, with the low byte first and the high byte second.

OVERVIEW

Total length of data packet is 772 bytes, including 48 bytes for the header file, 720 bytes for the laser return data and 4 bytes for the CRC32.




Figure 1 - Format of point cloud information packet

The total length of a data frame is 772 bytes, including:

- Frame header: 48 bytes
- Data block: $180 \times 4 = 720$ bytes
- CRC32: 4 bytes

DEFINITION OF HEADER

Total length of data packet is 772 bytes, among which 48 bytes represent the header, 720 bytes represent the data returned by laser and 4 bytes represent the CRC32.

OFFSET	LENGTH	DESCRIPTION	REMARK
0	2	Identifiers. Fixed as 0xFEAC	
2	2	Protocol Version: 0x0301	Protocol Version: 0x0301
4	4	Packet size, including header + data+CRC32	Packet size, including header + data+CRC32 Total bytes
8	2	Head size	The number of bytes in the packet header of this packet
10	1	Distance ratio	Used to calculate the distance. Distance = Distance count x Distance scale. For current proximity products, this scale value is 1, unit mm
11	1	Data type of data area	0x01:range (uint16) + intensity (uint16)
12	2	Scan count, starting from 0 and restarting from 0 when the limit is reached	Scan count from power-on, 0, 1, 2.....65535, 0, 1.....
14	2	Packet counting, starting from 0 and restarting from 0 when the upper limit is reached	Count of packets sent from power-up, 0, 1, 2.....65535, 0, 1.....
16	4	Timestamp, NTP64 format, fractional part	The decimal part of the NTP64 format timestamp, which can be synchronized with the timestamp server. Unsynchronized indicates the time from the start of the main program; synchronized indicates the time from 1900-01-01 00:00:00
20	4	Timestamp, NTP64 format, integer part	The integer part of the NTP64 format timestamp, which can be synchronized with the timestamp server. Unsynchronized indicates the time from the start of the main program; synchronized indicates the time from 1900-01-01 00:00:00
24	2	Bit[14:0]: Rotational Speed, Unit: 0.01Hz; Bit 15: Rotation direction (0: Clockwise, 1: Counterclockwise)	LiDAR real-time rotational speed. The highest bit indicates the direction of rotation: 0 represents clockwise, 1 represents counterclockwise; the value of the lower 15 bits indicates the rotational speed, the unit RPM (revolutions per minute) and Hz relationship: RPM = Hz × 60

OFFSET	LENGTH	DESCRIPTION	REMARK
26	2	Points included in 360 ° for calculating horizontal angular resolution	Indicates the number of angles in the range of 360 degrees, which is used to calculate the angular resolution. For example: 1600 means the angular resolution is $360/1600=0.225^\circ$
28	2	Input	Input IO state, Bit[3:0] corresponds to Input3~0
30	2	Output	Output IO status, Bit[3:0] corresponds to Output3~0
32	4	System Status	0 indicates normal operation, and each Bit indicates a state. Bit31:Not ready, Bit0:Motor fault, Bit1:Voltage, Bit2:Temperature, Bit3:Measurement system
36	2	Scan start point serial number, starting from 0	Scan the starting point serial number, convert the angle: serial number \times the above calculation of the angular resolution, such as the angular resolution calculated after getting 0.25, serial number value of $400 \times 0.25 = 100^\circ$
38	2	Scan end point serial number, starting from 0	Scan the last point serial number, convert the angle: serial number \times the angular resolution calculated above, such as the angular resolution calculated after getting 0.25, serial number value of $1000 \times 0.25 = 250^\circ$
40	2	The starting point serial number of this package start from 0.0 represents 0°	This package starting point serial number, conversion angle: serial number \times the above calculation of the angular resolution, such as the angular resolution calculation to get 0.25 after the serial number value of $400 \times 0.25 = 100^\circ$
42	2	Number of measurement points in this package N	The number of points contained in this packet.
44	4	Reserved	

DEFINITION OF BLOCK

The length of data block is 720 bytes and contains:

- 2 bytes related to distance
- 2 bytes related to the signal strength for the 180 points acquired in each packet.

OFFSET	LENGTH	DESCRIPTION	REMARK
0	2	Distance reading 0, unsigned integer which is, "the value of the reading × the distance ratio of the package head" to get the measurement distance (unit: mm)	The distance reading, together with the distance ratio, calculates the measured distance. Measured distance = distance reading × distance ratio in the package head. Example: reading 100, proportion 1, the measured distance is $100 \times 1 = 100$ mm
2	2	Signal strength reading 0, unsigned integer	
4	2	Distance reading 1, unsigned integer which is, "the value of the reading × the distance ratio of the package head" to get the measurement distance (unit: mm)	The distance reading, together with the distance ratio, calculates the measured distance. Measured distance = distance reading × distance ratio in the package head. Example: reading 100, proportion 1, the measured distance is $100 \times 1 = 100$ mm
6	2	Signal strength reading 1, unsigned integer	

DATA CONVERSION

Angle calculation

The calculation of the LGS-A10 angle is shown in the following example.

1. The 27th/28th byte of the header file converts the points contained in 360° to calculate the horizontal angular resolution. For example: 1440 means the angle resolution is $360/1440=0.25^\circ$.
2. Conversion angle: serial number × the angle resolution calculated above, for example, the serial number value is $400 \times 0.25 = 100^\circ$.

Distance calculation

The distance calculation for LGS-A10 is shown in the following example.

1. Obtain distance value: 0x11 & 0x12
2. Byte High-Low Swap: 0x12 & 0x11
3. Combine to unsigned hexadecimal number: 0x1211
4. Convert to decimal numbers: 4625
5. Multiply the distance ratio: Assume a distance ratio of 1mm
6. Result: 4625 mm

Calculation of signal strength


The signal strength of LGS-A10 is calculated as shown in the following example.

1. Obtain signal strength values: 0x11 & 0x12
2. Byte High-Low Swap: 0x12 & 0x11
3. Combined into unsigned hexadecimal numbers. 0x1211
4. Convert to decimal numbers: 4625
5. Result: 4625

CHAPTER 6

PARAMETER CONFIGURATION

CONFIGURATION THROUGH LGS PRO PC SOFTWARE



If you upgrade or downgrade the LGS Pro app, first uninstall the current version through the Windows Control Panel (Control Panel\Programs\Programs and Features).

The LGS Pro software interface is shown below.




Figure 1 - Sample of PC software interface



The PC software interface may change due to product update.

Operating environment

The required environment for the software to run is as follows:

- OS: Windows 10 and above
- .NET Framework: 4.5.2

Network environment

The default factory static IP for LiDAR is as follows:

- LiDAR IP: 192.168.1.100
- Net mask: 255.255.255.0


The following static IP must be configured on the PC:

- Host IP: 192.168.1.10
- Net mask: 255.255.255.0

Using LGS Pro

Menu tabs

The menu tabs have the following functions:




Home: shows the home page of LGS PRO containing the 3 options:

- New: to create, edit, save and upload a new configuration to the device.
- Open: to open and view a configuration previously saved locally on the PC.
- Monitoring: allows the plotting of the data transmitted by the device.




Settings: shows the “Wire Connection” option that contains the pin-functionality match of the Lidar:

2	GND	BLUE
3	INPUT_1	WHITE
4	INPUT_2	GREEN
5	INPUT_3	PINK
6	INPUT_4	YELLOW
7	GND_I/O	BLACK
8	OUTPUT_1	GREY
9	+VCC_I/O	RED
10	OUTPUT_2	VIOLET
11	OUTPUT_3	GREY/PINK
12	OUTPUT_4	RED/BLUE



Language: shows the list of languages supported by the GUI




Help: shows 4 options:

- User Manual: contains the link to the Datasensing site with the LGS-A10 user manual
- Factory Reset: shows information about the model, FW and HW version, network settings of the device and allows you to reset the device to factory settings
- Firmware Upgrade: upgrades the LiDAR firmware
- LiDAR Web Page: allows you to open the LiDAR configuration window (see figure below):



The “LiDAR Web Page” option is displayed only after connecting to a device and pressing the next button.

NOTE



Datasensing LiDAR Config

Model: LGS-A10
 MAC: 50-54-7B-B4-53-8E
 HardVer: 0.4.0
 SoftVer: 0.0.8

LiDAR Config

Motor RPM:

Angle offset: ° (0.00~360.00°)

Temperature

Main board: 52.9 °C

Recv board: 56.4 °C

Net Config

Host IP & Port: &

DHCP: ON OFF

LiDAR IP:

Net Mask:

Gateway:

NTP: ON OFF

Voltage

CPU core: 3.30 V

Recv board: 167.17 V

Miscellaneous

Motor speed: 599.9

Points/Circle: 1440

Zoneset: 3

Detection/Ns: 5_01

DATASENSING





Alternatively, the LiDAR configuration window can also be opened by typing the device’s IP on a web browser.

NOTE

Online configuration

Clicking on the “New” button on the Home page brings up the page to perform the search for devices connected to the PC.



If one or more devices are connected to the PC, the column on the left shows the list of those devices. When a device is selected, information about the device is displayed in the central part of the interface.

If all devices are not displayed, press the “Find” button to scan the LiDARS

Press the NEXT button to continue with configuration creation/editing.



The GUI gives the possibility to draw maximum of 3 areas (OUT1, OUT2 and OUT3) for each of the 16 Zonesets (from Zoneset[0] up to Zoneset[15]).


1. First select the Zoneset[x]
2. Select an area
3. Choose one of the tools to draw the areas
4. Areas are displayed within the Cartesian plane.
5. It is possible to edit a point by changing its coordinates from the keyboard



NOTE

This point applies only to the “Polygon” and “Line” drawing tools. The “Rectangle” tool does not allow area coordinates to be edited from the keyboard.


6. You can choose to display coordinates in Cartesian or polar form
7. When the area design has been finished, pressing the “Save to sensor” button transfers the configuration to the LiDAR.
8. Clicking on the “Area” tab in the left column, you can choose the values of Detection Capability and Number of Scan (Ns). The latter value is used to calculate the response time.



9. Press **New** to create a new configuration. All previously drawn areas are deleted.
 Press **Open** to open a configuration file previously saved locally in the PC
 Press **Save** to save the configuration created locally in the PC


Offline configuration

To create an offline configuration or if there are no devices connected to the PC, click on “Supported LiDAR” on the home page of the “New” page and then NEXT.




The next page has the same functionality as the online configuration except for the function “Save to sensor” (which allows you to send the configuration to the device).

Monitoring



Clicking on the “Monitoring” button brings up the page to perform a search for devices connected to the PC.


Select the device whose status you want to monitor and press the NEXT button. The following page is displayed:




The following information are displayed:

1. The Zoneset and related areas that the LiDAR is monitoring with the status of the outputs related to the areas.
2. The value of the RPM and the number of points transmitted by the LiDAR at each full rotation of scanning.
3. The Detection Capability and Number of Scan (Ns) values selected by the user for the Zoneset[x] and used during scanning from the LiDAR.
4. The collected points and areas.
5. The Angle and Range coordinates of the point where the mouse is located.

The icons of the three outputs OUT1, OUT2, and OUT3 are grayed out if there are no objects larger than the chosen Detection Capability in the selected area.




On the other hand, if the Lidar detects intrusions, the label for the intercepted area is activated.




Basic measurement


Angles start from 0° in the point behind the LiDAR and go on counterclockwise up to 360°:



Angle 0° == 360°



Angle 0° == 180°



Angle 0° == 270°

To set an offset angle, go to the configuration page (see "Parameter Configuration" on page 17). The offset angle is added to the actual angle of each point, causing a counter-clockwise rotation of a cloud of points:



Offset = 0°



Offset = 45°



Offset = 90°

Zone set switch


LGS-A10 allows to switch up to 16 zone set scenario by combination of the four related inputs according the table below. The default zone set is the #15, and corresponding to all the inputs not connected (floating). Take care to connect all the inputs to GND_I/O in case you want to start your process with zone set # 0.

ZONE SET #	INPUT 1	INPUT 2	INPUT 3	INPUT 4
0	GND_I/O	GND_I/O	GND_I/O	GND_I/O
1	+VCC_I/O (OR floating)	GND_I/O	GND_I/O	GND_I/O
2	GND_I/O	+VCC_I/O (OR floating)	GND_I/O	GND_I/O
3	+VCC_I/O (OR floating)	+VCC_I/O (OR floating)	GND_I/O	GND_I/O
4	GND_I/O	GND_I/O	+VCC_I/O (OR floating)	GND_I/O
5	+VCC_I/O (OR floating)	GND_I/O	+VCC_I/O (OR floating)	GND_I/O
6	GND_I/O	+VCC_I/O (OR floating)	+VCC_I/O (OR floating)	GND_I/O
7	+VCC_I/O (OR floating)	+VCC_I/O (OR floating)	+VCC_I/O (OR floating)	GND_I/O
8	GND_I/O	GND_I/O	GND_I/O	+VCC_I/O (OR floating)
9	+VCC_I/O (OR floating)	GND_I/O	GND_I/O	+VCC_I/O (OR floating)
10	GND_I/O	+VCC_I/O (OR floating)	GND_I/O	+VCC_I/O (OR floating)
11	+VCC_I/O (OR floating)	+VCC_I/O (OR floating)	GND_I/O	+VCC_I/O (OR floating)
12	GND_I/O	GND_I/O	+VCC_I/O (OR floating)	+VCC_I/O (OR floating)
13	+VCC_I/O (OR floating)	GND_I/O	+VCC_I/O (OR floating)	+VCC_I/O (OR floating)
14	GND_I/O	+VCC_I/O (OR floating)	+VCC_I/O (OR floating)	+VCC_I/O (OR floating)
15	+VCC_I/O (OR floating)	+VCC_I/O (OR floating)	+VCC_I/O (OR floating)	+VCC_I/O (OR floating)

Detection capability

LGS-A10 can be programmed by LGS_PRO user interface with different object capability detection during the configuration session.

Each zone set can have its own Detection capability by simply selection on “area” tab



The user can select up to 4 choices (2..5), the value means the minimum number of adjacent measuring points to find into the selected area that are necessary to switch-off the related OUT

The smaller is the number, the more the device detect small objects (High sensitivity)

The larger is the number, the more the device detects large objects but may not detect smaller one. (Low sensitivity)

In order to avoid false output switching, it's recommended to use low sensitivity values (4 or 5) in harsh environment with strong presence of dust or pollution.

It's possible to estimate the minimum detectable object by using this formula:

$$Dc=2 \times d \times Ac$$

Where:

$Dc(mm)$ = Detection capability = diameter of the base of a fullmade cylindric test piece

$d(mm)$ = Distance between center of LGS-A10 and center of the cylindric test pieces

Ac = coefficient dependent to selected angular resolution

= 0,0080 for angular resolution = 0,25° (600 rpm or 10Hz)

= 0,0085 for angular resolution = 0,5° (900 rpm or 15Hz)

= 0,0128 for angular resolution = 1° (1500 rpm or 25Hz)

Reset the LiDAR

The FactoryReset software program can be used to restore the following settings to factory configuration:

- IP: 192.168.1.100
- Host: 192.168.1.100:2368

From the LGS Pro software program go to *Help > Factory Reset*. The following window is displayed. Click on the *Reset(S)* button to restore settings to factory configuration.




Figure 2 - ResetConfig software program




NOTE

After performing a FactoryReset with subsequent power cycle, it is always necessary to load a configuration.

Firmware upgrade

Going to *Help > Firmware Upgrade* opens the firmware upgrade module:



To upgrade the firmware, follow the procedure below:


1. Click on the gray box to the right and select the .ldrup firmware file (or drag it to the specified area).



Check the “Continuous mode” box to automatically upgrade the firmware on each device that will be consecutively connected to the computer.

NOTE

2. Click on the *Upgrade* button.



3. Power cycle the device while keeping LGS Pro connected. The progress bar will fill up.
4. Open the LiDAR configuration web page and check that the firmware has been upgraded.

CHAPTER 7

TECHNICAL PARAMETERS

GENERAL SPECIFICATIONS

Wavelength	905 ± 20 nm
Laser class	Class 1
Channel	1
Scanning angle	360°
Scanning rate	10,15, 25 Hz
Ambient light limit	>80000 LUX @ sunlight
Light spot divergence angle	8(H); 3(V) mrad
Horizontal plane error	<= 0,8°

INTERFACE

Interface type	IEEE 802.3u 100Mbps Ethernet
Protocol	UDP TCP/IP

ELECTRICAL SPECIFICATIONS

Supply voltage (for LGS and I/Os)	9 to 30 VDC
Power consumption (25°C)	< 5W @15Hz
Input Max current	50 mA
Input Voltage Min for ON status	0 V
Input Voltage Max for OFF status	VDC-0.1 V
Input Impedence	6.8 KΩ
Input max switching frequency	4.5 / 6.5 / 10 Hz
Input protection	36 V
Output Max load current	50 mA
Output Voltage Min ON Status	0.7 V
Output Voltage Max OFF Status	VDC
Output Voltage Drop Max	30 V
Output Max Capacitive Load	1 uF
Output Max Capacitive Load	2.2 mH
Output Max Switching Frequency	8 / 11 /16 Hz
Output Protection	85° C
Power connector	12pin, M12x1 Connector Standard
Communication Interface	4pin, M12x1 socket D-coded

MEASUREMENT PARAMETERS

Absolute accuracy	<± 30 (0.4~10m)
Repeat accuracy	<= 20 (0.4~10m)
Angle resolution	0.25° @ 10 Hz / 0.5° @ 15 Hz / 1° @ 25 Hz
Working distance (based on reflectivity)	0.1~10m @ 80%
Resolution of output distance	1 mm
Point cloud density	14.4K@10Hz, 10.8K@15Hz, 9K@25Hz
Signal intensity	0-20000

AMBIENT CONDITIONS

Operating temperature	-10 to +60 °C
Storage temperature	-20 to +70 °C
Relative humidity	< 95% (No Condensation)

MECHANICAL SPECIFICATIONS

Housing width	65 mm
Housing length	65 mm
Housing height	70 mm
Degree of protection	IP67
Material	Body and cap: aluminum Window: polycarbonate Panel and LED cover: polycarbonate and ABS
Mass	< 500 g

COMPLIANCE AND CERTIFICATIONS

Vibration	IEC 60068-2-6:2007
Shock	IEC 60068-2-27:2008
EMC	IEC 61000-6-2:2016-08 / IEC 61000-6-3:2006-07
Laser safety	IEC 60825-1
ROHS	✓
Safety requirements	UL61010-1

INDICATORS

LED indicator	RGB*2 Color
Operation indicator	Green LED: Power ON
Function indicator	Red LED: LiDAR fault

SOFTWARE

Basic software	Datasensing LGS PRO OS required: Windows 10 and above
----------------	--

CHAPTER 8

TROUBLESHOOTING

PROBLEM	SOLUTION
LiDAR fails to scan	<ul style="list-style-type: none">• Check power connection• Check whether voltage meets 9 to 30 VDC If failure persists, contact Datasensing Technical Support.
LiDAR scan produces no data	<ul style="list-style-type: none">• Check net connection• Check the IP setting of the data receiver• Try to use a third-party data capture tool to check whether data can be obtained normally• Check if only one LiDAR software is started• Verify that the firewall on the receiving end of the data is turned off, or that there is no other security software or process blocking data transmission. If failure persists, contact Datasensing Technical Support.

APPENDIX A

DATA PACKET

The screenshot displays the Wireshark interface for an Ethernet network. The top pane shows a list of 15 UDP packets, all originating from 192.168.1.100 and destined for 192.168.1.20. The selected packet (No. 655) is expanded to show its structure:

- Frame 1: 814 bytes on wire (6512 bits), 814 bytes captured (6512 bits) on interface \Device\NPF_{1C87C1...}
- Ethernet II, Src: Nanjing_04:54:89 (50:54:7b:b4:54:89), Dst: Dell_3c:93:fc (a0:29:19:3c:93:fc)
- Internet Protocol Version 4, Src: 192.168.1.100, Dst: 192.168.1.20
- User Datagram Protocol, Src Port: 2368, Dst Port: 2368
- Data (772 bytes)


The bottom pane shows the raw data in hexadecimal and ASCII. The hex dump starts with:

```

0000 a0 29 19 3c 93 fc 50 54 7b b4 54 89 08 00 45 00
0010 03 20 01 64 00 00 00 11 b2 a0 c0 a8 01 64 c0 a8
0020 01 14 09 40 09 40 03 0c 32 e3 ff ff 01 03 04 05
0030 00 00 30 03 01 01 2d 00 64 01 07 a3 70 7d 0d 00
0040 00 00 58 82 a0 05 00 00 00 00 00 00 00 00 00
0050 9f 05 d0 02 b4 00 00 00 00 bf 06 93 02 b2 06
0060 91 02 b2 06 9c 02 b2 06 aa 02 ab 06 ab 02 ab 06
0070 ab 02 b2 06 a0 02 ab 06 ab 02 b2 06 a1 02 b2 06
0080 a0 02 b2 06 a3 02 b2 06 a9 02 b2 06 a6 02 b2 06
0090 a3 02 b2 06 97 02 b2 06 99 02 b2 06 94 02 b2 06
00a0 96 02 b9 06 8e 02 b9 06 8d 02 bf 06 87 02 cd 06
00b0 80 02 2b 06 90 02 45 03 f8 02 0f 03 cf 02 f4 02
00c0 64 02 b1 02 db 01 60 02 66 01 38 02 1a 01 26 02
00d0 22 01 18 02 23 01 0e 02 07 01 0d 02 10 01 04 02
00e0 2a 01 08 02 3f 01 0b 02 49 01 05 02 52 01 fd 01
00f0 4e 01 01 02 3d 01 06 02 2b 01 02 02 1d 01 02 02
0100 1a 01 fb 01 1d 01 fd 01 20 01 fd 01 24 01 fd 01
0110 27 01 04 02 23 01 09 02 19 01 0a 02 8a 01 09 02
0120 1f 01 06 02 2c 01 06 02 2d 01 0b 02 26 01 0b 02
0130 24 01 0b 02 22 01 09 02 1c 01 09 02 1f 01 04 02
0140 22 01 04 02 25 01 ff 01 29 01 ff 01 2e 01 00 02
0150 33 01 01 02 3a 01 05 02 55 01 10 02 86 01 18 02
  
```

APPENDIX B

MECHANICAL DIMENSIONS



APPENDIX C

RECOMMENDATIONS FOR MECHANICAL INSTALLATION

1. Protect the product respect to high shock and vibration source.
2. Do not expose it to any direct sunlight (windows, skylights) or any other heat source in order to keep the temperature as the standard profile
3. It is recommended that the installation base used to fix the LiDAR be as flat as possible without any unevenness.
4. The positioning posts on the installation base should strictly follow the depth of the positioning posts at the bottom of the LiDAR. The height of the positioning posts should not be higher than 4mm. The material of the mounting base is recommended to be aluminum alloy or similar metallic material.
5. When installing the LiDAR, if there are contact mounting surfaces above and below the LiDAR, please ensure that the distance between the mounting surfaces is greater than the height of the LiDAR to avoid damaging to his parts.
6. When installing and wiring the LiDAR, do not pull excessively the wires and keep it a bit loose.
7. In order to avoid any impact on measurement accuracy due to mutual interference between LiDARs, we recommend installation as shown below




Figure 1 Multiple LiDARs on the same plane to prevent optical path crosstalk




Figure 2 Multiple LiDARs forward placement




Figure 3 Multiple LiDARs window covers placed opposite each other




Figure 4 Multiple LiDARs bottoms placed opposite each other




Figure 5 LGS-A10 light output position and receiving position

APPENDIX D

CLEANING OF SENSORS

In order to accurately sense the surrounding environment, LGS-A10 needs to be kept clean, especially the ring-shaped optical window.

Precautions

Please read the contents of this Appendix D carefully and completely before cleaning LGS-A10 LiDAR otherwise improper operation may damage the equipment.

Required materials

1. Clean fiber cloth - ref. maintenance accessory "SLS-CLOTH" 95ASE3000
2. Spray filled with clean water
3. Anti-static alcohol free solution - ref. maintenance accessory "SLS-CLEANER" 95ASE2990
4. Clean gloves

Cleaning method

If there is only some dust adhered to the surface of the radar, you can directly use the clean fiber cloth 95ASE3000 with a small amount of anti-static alcohol free solution 95ASE2990 to gently wipe the surface of the window LiDAR, and then wipe it dry with a dry and clean fiber cloth.

If the surface of LiDAR's optical window is stained with lumps of foreign matter such as mud, clean water should first be sprayed on the surface of the dirty parts to remove the mud and other foreign matter.



CAUTION

Do not wipe off the mud directly with a fiber cloth, as this may scratch the surface irreparably).

If the first operation result not effective, secondly, spray warm water, with eventually mild soap, on the dirty area.

The lubricating effect of soapy water can accelerate the removal of foreign matter.

Gently try to wipe the surface of the LiDAR with the fiber cloth again, but be careful not to scratch the window surface.

Finally, clean the soap residue on the LiDAR surface with clean water (if there is still residue on the surface clean it again with anti-static alcohol free solution), and wipe it dry with a dry microfiber cloth.

NOTES

© 2024 Datasensing S.r.l. • All rights reserved • Without limiting the rights under copyright, no part of this documentation may be reproduced, stored in or introduced into a retrieval system, or transmitted in any form or by any means, or for any purpose, without the express written permission of Datasensing S.r.l. • Datasensing and the Datasensing logo are trademarks of Datasensing S.r.l.



Datasensing S.r.l.

Strada S. Caterina 235 | 41122 Modena | Italy
Tel. +39 059 420411 | Fax +39 059 253973